Hypex remote

www.hypex.nl

Control buttons



Package contents

- Hypex Infrared remote controller
- Battery CR2032 3V
- Manual

Functions

	Function	RC-5 code*
1	Power	50
2	Volume up	51
3	Volume down	52
4	Move left	55
5	Move right	54
6	Select	48
7	Mute	53
8	Function 1	56
9	Function 2	57
10	Function 3	59
11	Function 4	61

Device code 16

*Standard Philips RC-5 protocol

Installation

1. Remove the battery cover.
2. Place a CR2032 battery with the '+' as in picture.
3. Put back the battery cover.



A: Body must make contact with clip A

Dimensions (mm)



Warranty

Hypex Electronics warrants this product for a period of two years after the original date of purchase against defects due to faulty workmanship or materials arising from normal use of the device. The warranty covers working parts that affect the function of the device. It does NOT cover cosmetic deterioration caused by fair wear and tear, or damage caused by accident, misuse or neglect. Any attempt to modify or take apart the device will void the warranty.

For questions regarding the functionality of this product please contact support@hypex.nl

230327 R6